CEL - Robox 2 - Mainboard

- ISSUE D3

Revision History

ev. Code	Date	Description	
Al	16/01/2019	1st release, with stepper motor drivers swapped to TMC2130s, 5V PSU beefed up to power a Pt as well as the on board requirements, and for use with the updated extruder boards RSX-PCB-EXI2-A. Mains detect and 115W230V detection circuit changed, with the intention of speeding up the detection capability to allow time to record the head position.	
в0.1	09/05/2019	1. Commonality of stepper motor outputs with Impact Head Rev C & Extruder rev B 2. Mains detect circuit replaced with MIC941H & H11L1SM 3. R37, R49, R47 & R74 removed. Sepper 50 rails tidled up 4. 3V3 decoupling caps added to sepper drivers 5. Sepper drivers moved from extruder boards to this mainboard, zif connectors kept but pinout updated 6. All TMC sepper drivers to X1 type (TCIPF) 7. J27 pin 1 fan option 2 direct to GND?	
B0.2	10/05/2019	I2C added to extruder zif connectors (all TMC DCIN pins to tie low to free up MCU pins) On board temperature sensor DI2 DNF R58 reinstated	
B1	04/06/2019	Sepper pinout swapped for routing - but compatible with the standard. FRF1 connected to 3V3 not GND.	
C0.1	04/05/2020	Swapped stepper motors to step-stick modules for review	
C0.2	06/05/2020	Swapped from dual step sticks to jumper selection	
C0.3	15/05/2020	L23 removed. Datapack released for quote (with rev B Gerbers) Some pin swapping to ease tracking	
C1	11/06/2020	Review comment tidyup, 089 altered to filter across R39. C59 downrated. Z_STOP_A and Z_STOP_B nets on processor moved to low res (10 bit) ADC pins to allow use with strain gauges - swapped with Z+_STOP and PWRHEAD_VDET respectively.	
C2	29/06/2020	Mains fuse added to BoM for installing into fuse holder	
Dl	22/12/2020	Q1 swapped to AON7524, R1 to 3K3, R2 to 47K. R2 moved to the other side of R1, and thermal area for Q1 increased	
D2	10/03/2021	R2 to 5K1	
D3	09/11/2021	U13 removed (further update required to remove tracking from pin 4 - not actually internally unconnected as stated in the datasheet)	

GENERAL DESIGN NOTES

1	

CEL - Robox 2 - Mainboard

01 TITLE PAGE.SchDoc

RBX-PCB-MB02

2

System 02 System.SchDoc













